


BriteTap® Chick & Poultry Feeder



8 58728 00412 7

1 Turn shield counter clockwise.



2 Hold feed tube level. Turn base counter clockwise:

- Metal base - 1 turn
- Plastic base - 4 turns

3 Fill with feed, scratch, grit or oyster shells.

4 Screw on lid clockwise.

5 Adjust shield height as birds grows to block them from perching on the base.

6  **Outdoor Use** 

Add rubber gasket when using outdoors -- prevents rain from dipping through gap between shield & feed tube and getting into base.

Position shield 3" above base to block rain from wetting feed.

Note: move feeder indoors during periods of heavy rain & wind.

Brooder Tip: place on a flower pot saucer to raise feeder & prevent bedding from getting into base.

Feeder tubes fit together. Add optional second tube to increase feed capacity.